OWNERS MANUAL

714AA Series ActiClean™

THANK YOU

Keeping a clean and healthy home just got easier with the American Standard ActiClean™ toilet.

Introducing the ActiClean toilet, the first self-cleaning toilet by American Standard. The ActiClean self-cleaning toilet-bowl system makes cleaning effortless. All it takes is one simple press of a button to activate the cleaning system and in minutes your bowl is sparkling clean.

ActiClean features two cleaning cycles, Deep Clean and Quick Clean, and comes with a 10 week supply of cleaning solution developed by the trusted Lysol® brand. ActiClean does not require electricity; it is powered by 4AA alkaline batteries (included) which last up to 1 year.

In this document you will find information on how to install and operate the ActiClean toilet, frequently asked questions, and troubleshooting guides. If you have any questions or or need help with installation or operation of your new toilet, you can rest assured that our Customer Service team is available to assist you. An installation video is also available on our website at:

www.americanstandard.com

At American Standard we continually work harder to raise the standard of daily living by making it easier, safer and more beautiful.



Lysol' is a trademark of Reckitt Benckiser and is used under license to American Standard.

Product names listed herein are trademarks of AS America, Inc. © AS America. Inc. 2016




7302204-100 EN




TABLE OF CONTENTS

Inside The Box	page 3
Care Instructions	page 3
If Removing An Existing Toilet	page 3
Back-to-Back Installation	page 3
Installation Instructions	page 4
Installing Cleaning Solution Cartridge	page 7
Operating Cleaning Cycles	page 8
Canceling A Cleaning Cycle	page 8
Canceling A Cleaning Cycle Child Lock ON/OFF	
	page 8
Child Lock ON/OFF	page 8
Child Lock ON/OFF ActiClean System Instructions	page 8page 8page 8
Child Lock ON/OFF ActiClean System Instructions Frequently Asked Questions	page 8 page 8 page 9 page 10

Inside The Box:



Nuts (3)



SOLD SEPARATELY





Bolt Caps (2)





Knobs (2)


AA Alkaline Batteries (4)











* For seat installation, see instructions included with seat.

Care and Cleaning

When cleaning your toilet, wash it with mild, soapy water, rinse thoroughly with clear water and dry with a soft cloth.



WARNING: Do not use in-tank cleaners. These products can seriously corrode fittings in the tank. This damage can cause leakage and property damage. American Standard shall not be responsible or liable for any damage caused by the use of in-tank cleaners.



WARNING: The Lysol cleaning solution was specially formulated to work with the ActiClean system. Please do not refill the bottle with any other cleaners. Refilling the container will void the warranty. Some chemicals could damage the parts inside of the tank, potentially causing a leak and the system to fail.



WARNING: Remember to practice safety precautions when operating the ActiClean system. If you have animals or children that may come in contact with the toilet, close the seat while a cleaning cycle is in operation.

BEFORE INSTALLATION:

IF REMOVING AN EXISTING TOILET










Caution: If leaving floor flange open for more than 1-2 hours, cover flange to prevent escaping sewer gasses.

Clean Flange


BACK-TO-BACK INSTALLATION




back-to-back installations.

Depending upon your plumbing and venting conditions, the flow from this toilet in a back-to-back installation may create a vacuum on the system and draw water from the opposing bowl. The National Standards Plumbing Code prohibits the use of a cross fitting for drainage as throw over is possible. The code does approve a directional "Y" style fitting with proper venting to direct the water downward and away from the other toilet.

pg3






A

WARNING: Do not use plumber's putty, pipe dope, or any other sealant on the water supply connection to this tank. If the connection leaks after hand tightening, replace the supply line. If the connection continues to leak with the new supply line, replace the fill valve. Warranty is void if any type of sealant is used on the water supply connection.




WARNING: Overtightening of water supply line nuts could result in breakage and potential flooding. If the connection leaks after hand tightening, replace the supply line.

pg**5**







Allow the tank to fill with water and check that the water level matches the indicated dimension (referenced on the back of the tank).

If the water level needs to be raised, move the fine level adjustment up one or two clicks.

If the water level needs to be lower, please refer to the Troubleshooting Guide on page 11.

B) Prime the system by flushing the product 5 times before use to achieve optimal performance.


PROPER FLUSHING METHOD:

Be sure to fully depress the handle down with each flush. Do not hold the handle down for extended periods of time as this could allow air to enter the system which will slightly degrade performance for a few flushes.

REMOVE ORANGE TABS FROM LOCKING RETAINER POSTS


Remove Tank Top from packaging and turn it upside down. Place on a clean countertop.

On the underside of the Tank Top, locate the Orange Tabs (A) shown in diagram below. To remove Orange Tabs (A) carefully slide off of Locking Retainer Posts.







Turn Tank Top right side up and place onto the tank. Make sure all excess packaging is removed prior to doing so.



LOCK AND UNLOCK POSITIONS



- A. Open the lid.
- B. The tank **Locking Knobs** should be set to the **UNLOCK** position to properly seat the **Tank Top** in place. If they aren't, turn them to **UNLOCK** position first.
- C. Then to lock the **Tank Top** in place, turn the **Locking Knobs** to the **Lock** position. This will ensure proper operation of the ActiClean cleaning cycles.






If access to the internal tank components is needed, first turn the **Locking Knobs** to the **UNLOCK** position. This will allow you to remove the **Tank Top** and work on the tank trim if needed.




REMEMBER: Before operating the ActiClean system, you must always be sure to turn the **Locking Knobs** to the **LOCK** position.



14

INSTALLING CLEANING SOLUTION CARTRIDGE

BEFORE INSTALLING THE CLEANING SOLUTION
CARTRIDGE, REMOVE CHILD RESISTANT CAP
LOCATED ON THE BOTTOM OF THE CLEANING
SOLUTION CARTRIDGE




-Child Resistant Cap

- 1 Remove the child resistant safety cap from the bottle
- 2 Insert the bottle straight down until it snaps into place
- 3 Press and hold either the QUICK or DEEP icon for three seconds until the LOW level indicator light goes off
- 4 Repeat steps 1 through 4 every time a new bottle is inserted to ensure proper operation


INSTALLING BATTERIES

Push tab on the Battery Compartment Cover (D) to open the Battery Compartment (B).

Place 4 AA Alkaline batteries **(C)** inside the Battery Compartment then secure the cover to the Battery Compartment **(B)**.



Control Panel Operation and Indicators



QUICK

Cleaning Cycles

Quick Clean
Quick Clean is best used for regular upkeep, in between deep cleanings. A Quick Clean cycle will
clean the inside of the toilet bowl in just one minute. We recommend using the quick clean cycle
1 time per week.



Deep Clean

Deep Clean is used for more thorough cleanings. It releases more cleaning fluid and the cycle is longer compared to a Quick Clean cycle. A Deep Clean cycle completely and thoroughly cleans the inside of the toilet bowl in 10 minutes. The result is a fresh scented, sparkling clean bowl! We recommend a deep cleaning 1 time per week.

To keep your toilet bowl looking its best use the Deep Clean cycle in conjunction with the Quick Clean cycle each week.

ActiClean™ System Instructions

To Activate Cleaning Cycle:

- Check bowl for debris and if necessary flush the toilet
- After flushing wait 30 seconds
- Open the control panel door to power the ActiClean™ system
- Select from either QUICK or DEEP cleaning cycles

Note if the selection is not made within 30 seconds the system will go to sleep

To Cancel a Cleaning Cycle:

- Push the QUICK or DEEP cleaning cycle icon a second time
- The cycle will stop and rinse the bowl after 30 seconds

Child Lock

- ON/OFF: Press and hold both QUICK and DEEP buttons for 3 seconds

To Install New Cleaning Solution Cartridge:

- 1 Remove the child resistant safety cap from the bottle
- 2 Insert the bottle straight down until it snaps into place
- 3 Press and hold either the QUICK or DEEP icon for three seconds until the LOW level indicator light goes off
- 4 Repeat steps 1 through 4 every time a new bottle is inserted to ensure proper operation

To Remove Empty Cleaning Cartridge:

- The bottle will need to be replaced shortly after the "LOW" icon is displayed
- Pull upward firmly to remove the empty bottle We encourage that you please recycle empty bottles

Frequently Asked Questions:

Can I refill the cleaner bottle with other cleaning liquids?

No. The Lysol cleaning solution was specially formulated to work with the ActiClean system. **Do not** refill the bottle with any other cleaners. Refilling the container will void the warranty. Some chemicals could damage the parts inside of the tank, potentially causing a leak and the system to fail.

Can I use the cleaner to clean my other toilets?

The bottle of cleaner is designed to work with the ActiClean system. It will not work on a toilet that does not have the ActiClean technology built into it.

Can I use rechargeable batteries with the ActiClean system?

No. For optimal performance only use Alkaline batteries. No other batteries, including Lithium and any rechargeable battery will work with the ActiClean system.

How often should I change the batteries?

Change the batteries when the word **REPLACE** is illuminated.

I'd like to change the handle to a finish that matches the fittings in my bathroom, will that affect performance?

Do **NOT** change the handle with anything other than an ActiClean handle as the performance will be affected. The ActiClean system operates on a dual-injection flush valve system which is unlike anything on the market. Therefore if you change the handle to anything that wasn't made to operate with the ActiClean VorMax flushing system the toilet will not function properly.

What do I do if my ActiClean system isn't operating the way it should or I am having issues with it?

Please review the ActiClean Troubleshooting section of the manual on page 10. If problem persists please contact Customer Care.

How do I know when the cleaning cycle is finished?

When a cleaning cycle is in progress, the button will be illuminated. It will turn off once the cycle is complete. Do not use the toilet while a cleaning cycle is in operation.

How do I turn the Child Lock ON or OFF?

To turn the child lock on or off press and hold both the QUICK and DEEP buttons for 3 seconds.

What is the difference between DEEP and QUICK cleaning cycles?

QUICK Clean dispenses 0.85oz (25ml) of cleaner.

Quick Clean is best used for regular upkeep, in between DEEP cleanings. A Quick Clean cycle will clean the inside of the toilet bowl in just one minute.

DEEP Clean dispenses 1.67oz (50ml) of cleaner.

Deep Clean is used for more thorough cleanings and releases more cleaning fluid compared to the QUICK Clean cycle. A DEEP Clean cycle completely and thoroughly cleans the inside of the toilet bowl in 10 minutes. The result is a fresh scented, sparkling clean bowl!

Also see "Fixture Troubleshooting Guide" on page 11 and "ActiClean" Unit Troubleshooting Guide" on page 10.

ActiClean[™] Unit Troubleshooting Guide

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
"Low" fluid light is illuminated even when bottle is still full	"Low" fluid light indicator has not been reset	Follow the ActiClean™ System Instructions "To Install New Cleaning Solution Cartridge" on page 8.
Tank top lifts away from china tank when a cleaning cycle has been activated	Tank top has not been secured with the locking knobs	Ensure tank top is securely fastened to china tank with by turning locking knobs to the "Locked" position.
The bowl does not fill up with water when a cleaning cycle has been completed	Tank top has not been secured with the locking knobs	Ensure tank top is securely fastened to china tank with by turning locking knobs to the "Locked" position.
No lights are illuminated when device is activated for either quick or deep clean cycle	Batteries are defective or depleted	Remove batteries and reinstall; ensuring batteries are installed in the correct orientation (follow the pattern in the battery recepetacle). If batteries are installed correctly and the device is still not functioning properly, please install four new AA alkaline batteries.
The cleaning system is not working properly or works intermittently	Batteries are defective or depleted	Remove batteries and reinstall; ensuring batteries are installed in the correct orientation (follow the pattern in the battery recepetacle). If batteries are installed correctly and the device is still not functioning properly, please install four new AA alkaline batteries.

Toilet Troubleshooting Guide See Step 8 and 10 For Diagram Problem | **Possible Cause Corrective Action** a. Turn water supply on. Water should fill tank to level indicated in Step 10. Does not a. Water supply valve closed. flush b. Supply line blocked. b. Shut off water supply, disconnect supply line and inspect all gaskets and washers. Reassemble. c. Trip lever not opening jet flapper c. Adjust settings according to adjustable screw setup in Step 8. to stop. d. Sand or debris lodged in d. Shut off water supply and disconnect supply line. Use pliers to pull filter and rinse clean. Re-assemble and turn supply line on. water control. Poor or a. Bowl water level too low. a. Check that refill tube is connected to water control and inserted into overflow tube sluggish without being kinked or damaged. flush b. Supply valve partly closed. b. Open supply valve fully. Be sure that proper supply tube size is used. c. Partially clogged trapway and/or c. Remove obstruction. Consult a plumber if necessary. drain pipe and/or vent. d. Supply pressure too low. d. Normal supply pressure must be at least 20 psi. e. Tank not installed tightly on bowl. e. Tighten bolts as shown in Step 7 to make sure the tank is touching the piers of the bowl in the front and back of the product. f. Re-prime bowl by flushing 5 times in a row allowing the tank to refill each time to f. Product has air stuck in waterways. achieve optimal performance. g. If water level is too low, follow instruction in Step 10. If water level is too high see g. Incorrect tank water level. "Toilet does not shut off" below. h. Trip lever not opening jet flapper h. Adjust settings according to adjustable screw setup in Step 8. i. Toilet lost prime. i. Reseat tank by shutting off water supply, disconnect supply line, remove tank mounting nuts, inspect all gaskets and reassemble. j. Trip lever not returning to j. Adjust trip lever nut by loosening the nut a quarter turn at a time clockwise original position. (reverse thread). k. Loss of prime due to depressing on k. Do not depress trip lever longer than 2 seconds for optimal performance. Depressing the trip lever too long. trip lever longer will negatively affect the toilet performance by causing a loss of prime. Re-prime bowl by flushing 5 times in a row allowing the tank to refill each time to achieve optimal performance. Toilet leaks a. Poor supply line connection. a. Review Step 9 of installation procedure. b. Poor bowl to tank/floor connection. b. Review Step 1 through 7 of installation procedure. c. Loose tank nuts. c. Tighten nuts, reinstall. d. Loose flush valve mounting nuts. d. Tighten nuts, reinstall. e. Tank to Bowl gaskets leak. e. Replace gaskets. f. Black rim flapper leaking. Inlet valve f. Clean debris from seal surface. Replace flapper seal as needed and adjust settings will periodically run and you will see according to adjustable screw setup in Step 8. water coming from port in to the bowl. g. Clean debris from seal surface. Replace flapper seal as needed and adjust settings g. Red jet flapper leaking. Inlet valve will periodically run. according to adjustable screw setup in Step 8. Toilet does a. Flapper seal leaking or deformed. a. Clean debris from seal surface. Replace flapper seal as needed. not shut off See web for more info. b. Sand or debris lodged in water control. b. Shut off water supply and disconnect supply line. Use pliers to pull filter and rinse clean. Re-assemble and turn supply line on. c. Adjust settings according to adjustable screw setup in Step 8. c. Flush valve chain too tight, holding flapper open. d. Water level is too high. d. Shut off water supply, flush the tank to empty all water. Disconnect the supply line from the inlet valve. Place a bucket under the inlet then detach the refill tube. Remove lock nut, then remove the inlet from the tank. Remove the locking tab from the valve by pushing down and then turning the valve head counterclockwise to unlock. Push the valve down one step (approx 1/8" / 3mm) at a time until the desired water level is achieved. Then replace lock tab, reinstall valve with the float cup parallel to rear wall, tighten the valve locknut and reconnect the supply line. Turn water supply on. Toilet bowl a. Wax ring not fully compressed. a. Retighten bowl-to-floor knobs. rocks after b. Floor not level. b. Use toilet shims and /or place a bead of caulk around the base of the toilet.

pg **11**

installation

ActiClean™ Toilet Limited Warranty

This toilet comes with a limited lifetime warranty on chinaware, a limited 10 year warranty on all mechanical parts of the toilet, 1 year warranty on electronic parts and a limited 1 year warranty on the toilet seat if included with product. If inspection of this AS America, Inc. ("American Standard") plumbing product, inclusive of the chinaware and all mechanical parts, confirms that it is defective in materials or workmanship, American Standard will repair or, at its option, exchange the product for the same or a similar model.

This limited warranty applies only to the original purchaser and installation of the products. In the event of a limited warranty claim, proof of purchase will be required — save sales receipts.

For this warranty to become effective, the warranty registration process must be completed via the internet or telephone per the warranty registration instructions.

This limited warranty does not apply to commercial installations. The warranty for commercial installations is 1 year on chinaware, 1 year on mechanical parts, 1 year warranty on electronic parts and a limited 1 year warranty on the toilet seat if included with product.

This warranty **does not apply** to local building code compliance. Since local building codes vary considerably, the purchaser of the product should check with a local building or plumbing contractor to ensure local code compliance before installation.

This warranty **will be void** if the product has been moved from its initial place of installation; if it has been subjected to faulty maintenance, abuse, misuse, accident or other damage; if it was not installed in accordance with American Standard's instructions; or if it has been modified in a manner inconsistent with the product as shipped by American Standard.

WARNING: This warranty **DOES NOT COVER** any damages caused by the use of in-tank cleaners. These products can seriously corrode the fittings in the tank. This damage can cause leakage and property damage. **American Standard will not be responsible or liable for any damage caused by the use of in-tank cleaners.**

American Standard's option to repair or exchange the product under this warranty does not cover any labor or other costs of removal or installation including any costs of any surrounding material such as tile or marble. American Standard is not responsible for any other incidental or consequential damages attributed to a product defect or to the repair or exchange of a defective product, all of which are expressly excluded from this warranty. (Some states or provinces do not allow the exclusion or limitation of implied warranties, so this exclusion may not apply to you.)

This warranty gives you specific rights. You may have other statutory rights that may vary from state to state or province to province, in which case this warranty does not affect such statutory rights.

In the United States:

American Standard Brands
P.O. Box 6820
Piscataway, New Jersey 08855
Attention: Director of Customer Care
For residents of the United States, warranty
information may also be obtained by calling the
following toll free number: (800) 442-1902
www.americanstandard.com

In Canada: AS Canada, ULC

5900 Avebury Rd. Mississauga, Ontario Canada L5R 3M3 Toll Free: (800) 387-0369 www.americanstandard.ca

In Mexico:

American Standard B&K Mexico S. de R.L. de C.V. Via Morelos #330 Col. Santa Clara Ecatepec 55540 Edo. Mexico Toll Free: 01-800-839-1200 www.americanstandard.com.mx

PLEASE COMPLETE AMERICAN STANDARD WARRANTY REGISTRATION PROCESS AND SAVE THIS WARRANTY INFORMATION

IMPORTANT: Registration of the toilet must be completed for this warranty to become effective. Your registration will make it easier to contact you in the event of a product recall.*

INSTRUCTIONS:

Register your toilet at http://www.americanstandard-us.com/customerservice/warranty/warrantyRegistration.aspx Please save your proof of purchase (sale receipt).

If you need assistance or do not have access to our website, please contact American Standard Customer Care at: (800) 442-1902. An American Standard representative will assist in completing the warranty registration.

* In California, your warranty rights remain intact even if you do not complete the registration process.

THIS WARRANTY IS NOT TRANSFERABLE FROM ORIGINAL CONSUMER PURCHASER.